



Crash Barrier Plus System

Component list




CB-K-STP-ADJ


Components (varies by installation)




Cable Brackets
HW-C-BRKT-ADJ



Corner Brackets
HW-K-BRKT-CNR-ADJ




Adjustable Strap 144.0"
HW-C-STP-ADJ



Hollow Extrusion
CB-EXT-PLUS-307


Tools Required



16mm (5/8 in)



24mm (15/16 in)



5/16" ALLEN KEY OR
BALL END DRIVE SHAFT




McCue Corporation
Peabody, Massachusetts, USA
+1 (800) 800 8503
customer@mc cue.com

McCue UK & Europe
Milton Keynes, United Kingdom
+44 (0)1908 365 511
uksales@mc cue.com


McCue Asia
迈客(厦门)有限公司
Xiamen, Fujian, China
+86-592-2200790

mc cue.com






- ① Pull thru plastic strap 12" past cap on standard length applications and secure cap to metal adjustable bracket with (2) 3/8-16 x 1.50 socket head cap screws using a 3/8" allen key.
- ② Slide the other end of the plastic strap into the plastic rail cavity until it comes out from other side.
- Tip: Bracket may be slid into the plastic rail for extra length connection at the other side as shown in detail -a-.




- ③ Pull thru plastic strap 12" past cap and secure cap to metal adjustable bracket with (2) 3/8-16 x 1.50 socket head cap screws using a 1/4" allen key.
- ④ Make sure plastic strap is fully tightned one of the brackets. Note; You may choose to fully tighten one of the metal adjustable brackets in this step.



⑤




⑤ Slide Steel Bracket up into plastic rail, followed by pushing CB metal End as you line up plastic rail and bracket. Tip; it helps to put hand thru the cap hole and grab the metal bracket to align. It's important for metal bracket to sit behind the internal bar and aligned with holes. Please note that the Corner will required different brackets.



⑥ Refer to Crash Barrier installation step 4, 7, 8. The 5/8" Diameter x 6.50" Concrete Anchors will need to go thru cable brackets. The depth of the anchors will be 5.25" or so once installed.

⑦ Pull the straps tight and secure with 3/8" allen key set really tight on both screws. Once Tighten, tuck extra strap thru bracket opening as shown in 7a. Finish with applying plastic caps on metal ends.

- ⑧ Here are all the continuous options for the Plus Adjustable Strap System.



Brackets on the middle overlap each other on continuous runs.
Corner brackets overlap each other and are different shape than the end brackets