
FLEX+ Pedestrian with Ground Guard


Installation Instructions



Kits




FPG-GG-K-END Pedestrian with Ground Guard End Post



FPG-GG-K-MID Pedestrian with Ground Guard Mid Post




FPG-GG-K-CNR Pedestrian with Ground Guard Corner Post




FPG-GG-K-R-8 Pedestrian with Ground Guard Rail Kit



PolyCore Base End FLX-C-B-END



Base Cover End FLX-BCV-END QTY: 1



100mm Pin (Black) FLX-PIN-100 QTY: 2



Flat Head Screw HW-FH-M12 QTY: 6




Anchor Washer HW-WSH-ANC QTY: 4




Damper HW-DPR QTY: 4

PolyCore Base Mid FLX-C-B-MID



Base Cover Mid FLX-BCV-MID QTY: 1



100mm Pin (Black) FLX-PIN-100 QTY: 4



Flat Head Screw HW-FH-M12 QTY: 8




Anchor Washer HW-WSH-ANC QTY: 4




Damper HW-DPR QTY: 4

PolyCore Base Corner FLX-C-B-CNR



Base Cover Corner FLX-BCV-CNR QTY: 1



100mm Pin (Black) FLX-PIN-100 QTY: 4



Flat Head Screw HW-FH-M12 QTY: 8




Anchor Washer HW-WSH-ANC QTY: 4



Damper HW-DPR QTY: 4

Base Core FLX-COR



Base Core FLX-COR QTY: 1

Cap **FLX-C-CAP**



Cap FLX-CAP QTY: 1




Post Washer FLX-WSH QTY: 4




Flat Head Screw HW-FH-M12 QTY: 4

Top Rail Connector FLX-C-TRC



Top Rail Connector FLX-TRC QTY: 1



100mm Pin (Black) FLX-PIN-100 QTY: 1



FastFit Insert **FLX-INS** QTY: 1



Flat Head Screw HW-FH-M12 QTY: 1



Button Head Screw HW-BH-M12 QTY: 1



Anchor Washer HW-WSH-M12 QTY: 1




Damper HW-DPR QTY: 1

Concrete Anchor (Imperial or Metric) HW-C-A1250 or HW-C-AM12-130



Concrete Anchor HW-C-A1250 or HW-C-AM12-130



Required Tools







Impact Driver



Vacuum





Mitre Saw



Hex Key 8mm [5/16in]



Measuring Tape



Socket Extender



Hex Socket 17mm [3/4in]



Hex Bit 8mm [5/16in]




Chalk Line




Marker





PPE recommended: High Visibilty Vest, Steel Toe Boots, Work Gloves, Ear Protection, Dust Mask, Eye Protection.















Step 7







Hammer Drill With ∅ 12mm or ∅ 1/2in Masonry Bit

Vacuum

HOLE DETAIL IMPERIAL HW-C-A1250



HOLE DETAIL METRIC HW-C-AM12-130





- PPE recommended: High Visibilty Vest, Steel Toe Boots, Work Gloves, Ear Protection, Dust Mask, Eye Protection.
- Clean concrete dust by running the vacuum during drilling.









Impact Driver


Extender


17mm [3/4in] Hex Socket





ANCHOR DETAIL







REPEAT FOR ALL POSTS
















REPEAT FOR ALL POSTS
















REPEAT FOR ALL POSTS

Appendix A: Custom Length Rails












Impact Driver


Socket Extender


Hex Socket 17mm [3/4in]


















Drill with 20mm [3/4in] Bit







Installation Complete

